



Detroit Speed
Fender Brace Kit
1967-69 Camaro/Firebird, 1970-81 Camaro
P/N: 011801DS & 011802DS

The Detroit Speed Fender Brace Kit is another way to beautify the engine compartment of your 1st or 2nd Generation Camaro. The Fender Brace Kit has 100% CNC machined Clevis' from 304 Stainless Steel. The kit includes fabricated mounting brackets and comes with button head stainless steel mounting bolts. The Fender Braces triangulate the radiator core support to the fender and are fully adjustable, a benefit not available with your stock Fender Braces.



P/N: 011801 (1967-69 Camaro/Firebird)

P/N: 011802 (1970-81 Camaro)

REMINDER: Use Anti-Seize on all mounting hardware.

1. Remove the factory braces from the vehicle.
2. Loosely install the mounting bracket on both the fender and the core support using the provided stainless button head screws.
3. Slide the clevis end on each mounting bracket and insert the provided bolts through each clevis. It may be necessary to adjust the overall length of each of the fender braces due to variations in factory production.
4. Tighten the mounting hardware along with the clevis bolts and the jam nuts.
5. Installation complete.

If you have any questions before or during the installation of this product, please contact Detroit Speed at tech@detroitsspeed.com or 704.662.3272

Legal Disclaimer: Detroit Speed, Inc. is not liable for personal, property, legal, or financial damages from the use or misuse of any product we sell. The purchaser is solely responsible for the safety and performance of these products. No warranty is expressed or implied.