



Detroit Speed
Heavy-Duty Front Sway Bar Endlink Kit
2010-15 Camaro
P/N: 031411DS

The Detroit Speed 2010-15 Camaro HD front sway bar endlink kit includes direct replacement links and hardware that are adjustable and stronger than stock.



Figure 1

1. With the car safely up on jack stands remove the front wheels.
2. Remove the OEM factory endlink.
3. Note the orientation of the pivot studs and replace with the corresponding Detroit Speed endlink assembly.

NOTE: Later model 5th Generation Camaro's have an OEM front sway bar using an M12 endlink stud. The provided washers on the endlink are intended to be used with OEM M12 sway bar and strut bracket. The washers will need to go on both sides of the strut bracket and sway bar. Use the provided adapter bushings when you connect the lower link stud to this sway bar.

4. Torque the endlink nut at the strut and at the front sway bar to 37 ft-lbs. See Figure 2 on the next page for installation photo.
5. Repeat the above procedure for the other side of the vehicle.

6. Put the front wheels back on and torque the lug nuts to proper OEM specs.



Figure 2 - Picture above shows the LH endlink installed

If you have any questions before or during the installation of this product, please contact Detroit Speed at tech@detroitsspeed.com or 704.662.3272

Legal Disclaimer: *Detroit Speed is not liable for personal, property, legal, or financial damages from the use or misuse of any product we sell. The purchaser is solely responsible for the safety and performance of these products. No warranty is expressed or implied.*