



Detroit Speed Adjustable Leaf Spring Pads

Fits all 3" axle tubes

P/N: 040201DS

The Detroit Speed leaf spring pads are used when installing a new rear end housing or when relocating your leaf springs to accommodate a larger rear tire. The steel adjustable leaf spring pads clamp to any 3" axle tube. The spring pads are compatible with 2-1/2" wide leaf springs.



1. Locate and center the axle housing and set the leaf spring pad width. Once the pinion angle is set, clamp the spring pads securely in position.
2. Draw the 1/2"-13 x 1-1/2" L Hex Head bolts down evenly around the 3" axle tube by hand with the 1/2" Nylock nuts and washers and then torque them to **10 ft-lbs. maximum.** **NOTE:** Failure to draw the bolts down evenly and then tightening the bolts to more than 10 ft-lbs. may cause permanent damage to the spring pads.
3. Once the mock-up procedure is complete with the pinion angle and the leaf springs in the final position, permanently attach the spring pads by **welding** the lower spring pad bases to the axle tubes. Use care when welding as excessive heat can distort the axle tubes. **NOTE: The spring pads must be welded to the axle tube before driving the vehicle.**

If you have any questions before or during the installation of this product, please contact Detroit Speed at tech@detroitsspeed.com or 704.662.3272

Legal Disclaimer: Detroit Speed is not liable for personal, property, legal, or financial damages from the use or misuse of any product we sell. The purchaser is solely responsible for the safety and performance of these products. No warranty is expressed or implied.